Galil EtherCAT Master Setup Guide



The DMC-52xx0 2, 4, 8, 16, and 32 axes Rev. 1.0d



The DMC-500x0 1-8 axes EtherCAT / 1-4 axes Local



Galil Motion Control, Inc. 270 Technology Way Rocklin, California 95765

> 916.626.0101 support@galil.com www.galil.com 09/23/16

Using This Guide

•

Note This manual is a supplement to the DMC-500x0 and DMC-52xx0 User Manuals and covers the installation and configuration of 3rd party external EtherCAT drives to interface with a Galil EtherCAT Master.

This setup guide provides information for proper set up and configuration of an EtherCAT station for use with a Galil EtherCAT Master. In addition, the EtherCAT Command Reference contains a description of the additional commands available with this option. It is recommended that the user download the latest version of the Command Reference and User Manual from http://www.galil.com.

The DMC-500x0 and DMC-52x00 motion controllers have been designed to work with many motor and drive combinations. For installation and configuration of servo or stepper motors using either Galil's internal amplifiers or 3^{rd} party external non-EtherCAT amplifiers, see the DMC-500x0 and DMC-52xx0 User Manuals.

Review the brief EtherCAT Glossary on page 58 to familiarize yourself with the terms used in this manual.



Contents

1 Overview 1.1 Galil EtherCAT Masters 1.2 Supported EtherCAT Drives and IO Modules	4 5
2 EtherCAT Communication 2.1 Overview 2.2 Supported EtherCAT Modes and Features	6 6
 3 Configuring EtherCAT Drives 3.1 AMC-DZE Servo Drive Series 3.2 Yaskawa ΣV and ΣVII Servo Drive Series 3.3 LS Mecapion Pegasus and L7NHA Servo Drive Series 3.4 Delta ASDA A2-E Servo Drive Series 3.5 Panasonic Minas A5B Servo Drive Series 3.6 Copley Xenus Plus Servo Drive Series 3.7 Sanyo-Denki R Advanced Servo Drive 3.8 Parker PD-10C Servo Drive Series 3.9 Estun ProNet Servo Drive Series 	8 14 17 29 21 24 27 29 35
4 Configuring EtherCAT IO 4.1 Galil RIO-574x0 EtherCAT IO 4.2 VIPA EtherCAT IO	37 37
5 Features and Limitations 5.1 General 5.2 Drive Limitations	38 39
6 DMC Quick Start Guide 6.1 Example 1: Single Axis Position Relative Move 6.2 Example 2: Four Axes and single IO EtherCAT Network Setup 6.3 Example 3: EtherCAT Error Handling	40 40 41
7 Appendices 7.1 I/O Pin Outs 7.2 Error Handling 7.3 EtherCAT Glossary 7.4 Galil BLM-N23-1000-B Specifications	42 45 49 50

9

1 Overview

1.1 Galil EtherCAT Masters

Galil offers two EtherCAT Masters, the DMC-500x0 and the DMC-52xx0. Features, capabilities, and a comparison of each platform is listed in Table 1 below.

Comparison	DMC-52xx0	DMC-500x0
Axis Count	Up to 32 axes of control (available in 2,4,8,16 and 32 axes configurations)	Up 8 axes of control (maximum 4 local)
Ethernet	(1) 10/100 Base-T	(1) 10/100 Base-T
EtherCAT	(1)	(1)
RS232	No	(1) Main, (1) Aux, 115 kbaud
USB	(1)	No
Allowed EtherCAT IO Slaves	(2)	(2)
Uncommitted Digital Inputs	(8) optoisolated	(8) optoisolated
Uncommitted Digital Outputs	(8) optoisolated, high power sourcing	(8) optoisolated, high power sourcing
Uncommitted Analog Inputs	(8) programmable	(8) programmable
Uncommitted Analog Outputs	(8) programmable	No
Compatible Drives	Supported EtherCAT amplifiers	Galil's entire line of internal servo/stepper amplifiers, external servo/stepper amplifiers, and supported EtherCAT amplifiers
Enclosure Dimensions	1.60" x 5.00" x 9.75"	8.05" x 7.25" x 1.41"

Table 1: Summary of features and comparison of Galil EtherCAT Masters

1.2 Supported EtherCAT Drives and IO Modules

The full part numbers for each drive and IO module currently supported and tested are listed below:

1.2.1 EtherCAT Drives

•

- AMC DZEANTU EtherCAT Servo Drive Series
- Copley Xenus Plus EtherCAT Servo Drive Series
- Delta ASDA-A2E EtherCAT Servo Drive¹
- LS Mecapion Pegasus EtherCAT Servo Systems
- LS Mecapion L7NHA EtherCAT Servo Drive Series
- Panasonic Minas A5B EtherCAT Servo Drive Series
- Sanyo-Denki RS2A01A0KA4 EtherCAT Servo Drive^{1, 2}
- Yaskawa ΣV (Sigma 5) and ΣVII (Sigma 7) EtherCAT Servo Drive Series
- Parker PD-10C EtherCAT Servo Drive
- Estun Automation ProNet Servo Drive Series¹

1.2.2 EtherCAT IO Modules

- Galil RIO-574x0 EtherCAT IO
- VIPA IM 053-1EC00 IO³

 $^{\rm 1}$ Hardware Latch and Latch on Index functions are not supported by these drives

² Home sensor not supported by these drives

³ See chapter 4 for specific IO hardware supported

Galil EtherCAT Master Setup Guide Rev 1.0d

2 EtherCAT Communication

2.1 Overview

•

The EtherCAT communication protocol is a deterministic, highly coordinated method of distributed control allowing fast communication between a Master and multiple Slave devices. The EtherCAT communication protocol is built on TCP/Ethernet, incorporating the physical and data link layers of the OSI networking model. This means that standard Ethernet hardware, Network Interface Cards and CAT5 cabling, can be used to relay communication between nodes at 100 Mbps.

Note Standard Ethernet hubs, switches and routers are not compatible with EtherCAT networks

2.2 Supported EtherCAT Modes and Features

Galil EtherCAT Masters operate in Cyclic Synchronous Position (CSP) Mode and Cyclic Synchronous Torque (CST) Mode¹. In CSP mode, motion profiling data is sent from the EtherCAT Master to the Slave at regular, deterministic intervals which the Slave then interprets via hardware and translates into motion. The Slave also returns data to the Master such as encoder position and I/O status. This streamlined amount of data allows for very tight control due to high update rates, for Galil EtherCAT Masters, the EtherCAT cycle time is 1 ms.

In addition to low cycle times, EtherCAT networks rely on the Distributed Clock feature to synchronize and coordinate communication. When an EtherCAT network is initialized, the Master measures communication times to and from each drive. Each drive is then assigned a time offset to ensure that commands are executed simultaneously with minimal latency.

The additional hardware and processing required on both the Master and Slave ends does increase the cost for an EtherCAT control system. Standard analog command line signals and 'dumb' drives will likely be lower cost for some time. However, for some applications the added cost is offset by the ease of wiring, upgradeability and versatility that EtherCAT offers for distributed control systems.

The EtherCAT standard also includes support for dedicated I/O modules. Communication with these modules is much simpler than with drives since no motion profiling is needed. Digital and Analog IO are queried and/or set at the rate specified by the EtherCAT Network Cycle Time. As a result, the RIO-574x0 and VIPA IO modules can be interfaced with a Galil EtherCAT Master with no additional set up needed. The RIO-574x0 offers programmable analog IO ranges among other other features. Consult the RIO-574x0 user manual for additional configuration details.

The EtherCAT standard defines a complex and tightly coordinated communication scheme with many hardware and software layers. Configuration and operation of an EtherCAT Master requires a working knowledge of Ethernet communications, programming, and complex logic.

<u>One the primary benefits of using a Galil EtherCAT Master is that all of the configuration of an</u> <u>EtherCAT network is handled in firmware</u>. All EtherCAT level communication is transparent to the user who can simply command motion on an EtherCAT axis as if it were a local axis powered by a Galil internal drive or external analog drive.

 1 Cyclic Synchronous Torque (CST) Mode is only supported on the DMC-500x0 with AMC DZEANTU and Yaskawa Σ 5 drives

3 Configuring EtherCAT Drives

•

This chapter is meant as a 'bare bones' guide that will get supported drives up and running with a Galil EtherCAT Master. For more advanced tuning or drive configuration options, consult the User Manual for your specific drive. Configuring EtherCAT Drives to function with a Galil EtherCAT Master involves using drive manufacturer software to make the drive's digital I/O accessible to the Master. In addition, some drives include error handling for various conditions such as excessive position or speed. In general, these features should be disabled to allow the Master to handle their associated error conditions.

This guide assumes that the EtherCAT drive and motor have been correctly configured as per by the drive manufacturer documentation.

3.1 AMC-DZE Servo Drive Series

•

The AMC-DZEANTU drives are a family of compact servo amplifiers that can be paired with a variety of motors. This chapter will detail the process of both resetting and configuring an AMC DZEANTU-020B080 drive to operate with a Galil BLM-N23-50-1000-B 3-phase brushless motor, hereafter referred to as a Galil BLM.

3.1.1 Resetting the Drive to Factory Defaults



1 Install DriveWare and Connect to the Drive

•

Install AMC's DriveWare Software (this guide uses version 7.3.2) on a Windows PC and start the application. When prompted with an Open/Connect window, select 'Connect' and then connect to the drive via the window shown in Figure 2. Be sure that Interface Access Control is set to 'Read/Write' and USB is selected for the Communication Interface.

Communication Interface RS232 RS2485 SynqNet Ethernet	Interface Settings Drive Address: USB Device: 64597-1004
Interface Access Control Access: Read/Write v	
OK	Restore Defaults Cancel
Figure 2: DriveN	Vare Connection Settings Window

2 Select and Download the Default Project File

During installation, DriveWare places the default project files in:

'Documents\DriveWare7.3.2\My Projects\Sample Projects'

Not Default project files are write protected although it is recommended to copy the files to an separate directory as backups.

Reconnect to the drive and when prompted to 'Upload/Download', select 'Download' and navigate to the above listed path. Select the "DZEANTU-020B080.Adf" file and click 'OK' to load the project into DriveWare. On the top menu bar, click the 'Apply' and 'Store' buttons. The AMC-DZEANTU drive has now been reset to factory defaults.

3.1.2 Configuring an AMC-DZE Drive for use with a Galil EtherCAT Master

This section will outline the steps necessary to configure an AMC-DZE drive to control a Galil BLM and interface with a Galil EtherCAT Master.

1 Rotary Switches

Set the drive's Station ID using the two rotary switches located on the front panel. This number is the address the EtherCAT Master will use to communicate with the drive. Each drive on the network should have a unique address to avoid communication conflicts.

2 Set Basic Drive Configuration

Connect to the drive via mini USB cable. Once connected, the main DriveWare window will load. This window includes a navigation bar on the left that will be used to view and configure parameters. See Figure 1.

The first menu item in the navigation bar shows the amplifier model currently saved and/or connected. Expanding the drive menu will open up four configuration options: 'Settings', 'Configuration 0', 'Loop Feedback' and 'Power-Up'. Select the 'Configuration 0' menu item.

The configuration settings to be used here will depend on the EtherCAT mode to be used; Cyclic Torque (Current) or Cyclic Position (Position Around Velocity). A brief description of each mode is listed in Table 2. Values are listed in Table 3. Note that CST Mode is only supported on the DMC-500x0 with AMC DZEANTU and Yaskawa Σ 5 drives.

Cyclic Synchronous Position Mode (CSP)	Cyclic Synchronous Torque Mode (CST)	
The DMC-500x0 EtherCAT Master sends cyclic position commands to the EtherCAT slaves, with the position and velocity loops being closed by the AMC amplifier. Cyclic Position mode should be set up in the Configuration window as shown in Figure 4.	The DMC-500x0 EtherCAT Master sends cyclic torque commands to the EtherCAT slaves, with the PID position loop closed by the DMC- 500x0. Current mode should be set up in the Configuration windows as shown in Figure 3.	
Figure 4: CSP Mode Settings Loop Configuration Position Around Velocity Gain Set 0 Gain Set 1 Command Limiter Offf Linear Ramp Accel/Decel	Loop Configuration Command Source Current No Command Image: Command Limiter No Command Image: Command Limiter Image: Command Limiter Image: Command Limiter Accel/Decel	

Table 2: CSP and CST mode descriptions

Setting	CSP Mode	CST Mode
Loop Configuration	Position Around Velocity	Current
Command Source	No Command	No Command
Gain Set	0	0
Command Limiter	Off	Off

Table 3: AMC DriveWare 'Configuration 0' values

3 Motor Parameters

•

The second menu item allows the entry of the motor parameters. These values must be taken from the motor datasheet in order to ensure proper motor operation within electrical and mechanical limits. The relevant Galil BLM values can be found in Table 32 in the Appendices.

The motor polarity can be set via the selection box at the bottom of the motor parameters box. Galil recommends configuring the rotation direction such that a forward (counts increasing) move is in the Clockwise direction.

4 Limits and Home Switches

The AMC-DZE drives are equipped with a bank of general I/O that the EtherCAT Master utilizes for limit and home switch sensors as well as the motor encoder index and hardware latches. In

order for the controller to read these inputs, it is necessary to disable the drive's default functions assigned to them. Expand the 'Inputs/Outputs' menu item and select the 'Digital Inputs' section. Remove any assigned function to inputs 1, 2, 3, and 4 by clicking the red X near the bottom right of the window. Also be sure that inputs 1,2, and 3 are set to 'Active Low'. See Figure 5.

5 Index & Hardware Latches

•

In order to set inputs 4 and 5 as the motor encoder index latch and hardware latch respectively, expand the 'Capture' menu item and drag/drop the 'High Speed Capture' item onto Inputs 4 and 5. Next, click the 'Capture Edit' button and set 'Captured Signal' to 'Primary Feedback Position'. Input 4 should be set to 'Active High', while input 5 should be set to 'Active

Input Functions:	Input As	signments:				
(a) User Action a) Motor ← Feedback (a) Position a) Capture → Sat/Reset Capture 6 → Sat/Reset Capture 7 (b) Home (c) Events (c) Mode (c) Mod	Input 1 2 3 4 5 6 6 7 8	Type GP GP HS:A HS:C GP GP GP	Active Low Low High High High High	Function High Speed Capture High Speed Capture	Captured Signal Primary Feedback P Primary Feedback P	Value O cnt O cnt
	< Input S Capi	ettings rure Edit		Active Low • A	ctive High	

Low' see Figure 5. Pin outs for the various IO can be found in Section 7.1.1.

Input	Туре	Active	Function	Captured Signal
1	GP	Low		
2	GP	Low		
4	HS:A	High	High Speed Capture	Primary Feedback Position
5	HS:C	Low	High Speed Capture	Primary Feedback Position

Table 4: AMC DriveWare Digital Input Settings

6 Event Handling

The 'Events' menu item lists functions that the drive will run automatically when certain events occur. In order to take advantage of the DMC-500x0 EtherCAT Master's event handling, uncheck the "Latch" box on the right of each item. All but two of these will need to be disabled on the drive.

The 'Comm Channel Error' Action needs to be set to 'Disable Power Bridge' to immediately shut down the drive in the event of a communications interruption between the drive and the DMC-500x0 EtherCAT Master. In addition, the 'Position Following Error' Action should be set to 'No Action' in order to allow access to the DMC-500x0 EtherCAT Master's automatic subroutines. See Figure 6.

Comm Channel Error	Disable Power Bridge	•		
PWM/DIR Broken Wire	Disable Power Bridge	-		
Velocity Following Error	No Action	-		
Position Following Error	No Action	-		
Figure 6: DriveWare Event Handling Settings				

7 Set Current Limits

•

In order to avoid damage to the motor, the AMC-DZE drive's current limits must be set to within motor datasheet specifications. Set the current limits for the Galil BLM as shown in Figure 7 and listed in Table 5.

Current Limits		Current Limiting A	lgorithm
Peak Current:	.00 Adc	Time-Based Line	miting
		RMS Charge-E	Based Limiting
0%	100%	Scaling Source:	None V
Peak Current Time: 1.000) s	g ood der	
-0			
0 s	65 s		
Continuous 5	.00 Adc		
0%	1008/		
Ealdhadr Timor 10.00	100%		
Totoback nine: 10.00			
0 seconds	65 s		

Parameter	Value
Peak Current	8.00 Amps
Peak Current Time	1.000 sec
Continuous Current	5.00 Amps
Current Limiting Algorithm	Time-Based Limiting

Table 5: DriveWare Current Limit Values

8 EtherCAT Communication Settings

Configure the AMC-DZE drive's network settings by expanding the 'Network' menu item. Table 6 lists the values necessary to enable communication between the AMC-DZE drive and the DMC-500x0 EtherCAT Master. 'Cyclic Torque' and 'Target Current' are valid settings for both torque mode and position mode.

Settings	RPDOs	TPDOs
Station alias: 1 Initial mode of Operation: Cyclic Torque Cyclic mode period: 1 msec	Word 0 - Control Word (6040:00) Word 1 - Target Current (6071:00) Word 2 - User Bits (2001:03)	Word 0: Status Word (6041:00) Word 1: Digital Inputs (2023:01) Word 2: Actual Position (6064:00) Word 3: Actual Position*

Table 6: EtherCAT Communication Setting Values

*'TPDO Actual Position' is a 2 byte value that spans Word 2 and Word 3.

9 Current Loop Gains

0

The AMC-DZE drive requires the user to tune the current loop based on the motor specifications. In the 'Tuning' menu item, expand the 'Current Loop Gains' item. These gains will vary with motor type and manufacturer. For the Galil BLM, values for K_P and K_I are listed in Table 7. Consult with AMC's technical support for specific instructions on tuning the AMC-DZE drive's current loop gains.

Parameter	Value
Current Loop K _P	4.857
Current Loop Kı	0.113

Table 7: Current Loop Gain Values for a Galil BLM

10 Position and Velocity Loop Gains

If planning to use the system in position mode, it is necessary to set the drive's position and velocity loop gains. These values are highly dependent on motor type and system mechanics. However for the purposes of setting up a free spinning (no mechanics coupled to motor) Galil BLM, the values listed in Table 8 list values that will provide sufficient servo control to confirm correct operation. Consult with AMC's technical support for specific instructions on tuning the AMC-DZE drive's velocity and position loop gains.

Parameter	Value
Velocity Loop K _P	6.10E-005
Position Loop K_P	0.003

Table 8: Velocity and Position Loop Gain Values for a Galil BLM

11 Motor Commutation

One of the last steps is to commutate the motor using DriveWare's 'AutoComm' function. Expand the 'Motor' menu item and click on the 'AutoComm' item. Click 'Start AutoCommutation' in the AutoComm window, and follow the prompts. This procedure will spin the motor shaft roughly 2.5 revolutions in each direction, setting the motor brushless modulus and hall sequencing. This process must be performed any time the motor is changed.

12 Save and Apply Changes

•

The final step is to save this configuration to a project file on the PC. Do so by going to File/Save Project in the top menu bar.

Note Be sure that the project is not saved over a default project file

Lastly, click 'Apply' then 'Store' in the top menu bar to write the changes to the drive's nonvolatile memory. Disconnect the software from the AMC-DZE drive, power cycling the drive is not necessary for the changes to take effect.

The drive is now configured to communicate with a Galil EtherCAT Master.

3.2 Yaskawa ΣV and ΣVII Servo Drive Series

The Yaskawa ΣV and ΣVII Servopacks are single drive systems which integrate both drive and motor into one package. As a result, there are only a few parameters that need to be set in order for the drive to interface with a Galil EtherCAT Master.

3.2.1 Resetting the Drive to Factory Defaults

1 Install SigmaWin+ Software and USB Drivers

Install the SigmaWin+ () version 5.56a shown below) drive configuration software on a Windows PC. SigmaWin+ requires that the USB drivers be installed manually. This can be done by opening the PC's Device Manager, selecting the Yaskawa item and selecting 'Update Driver'. Navigate to the file that contains the relevant USB driver and click 'OK'.

2 Connect to the drive

Connect the drive to the PC via mini USB cable. Open the SigmaWin+ application, select the drive type, then search for and connect to the drive.

3 Initialize the Drive

Click on the 'Edit Editing Window shown in

E

Parameter' icon in the toolbar to bring up the Parameter Figure 8.

Click the 'Initialize' Button to write default parameters to the drive.

Power cycle the drive for the changes to take effect.

Il constant number F	unction Selection(Pn0xx-) Gain(Pn1xx-) Position(Pn2xx-) S	peed(Pn3xx-) Tor	que(Pn4x	x-) Sequence(Pn5x	∝-) I/O Sigr_
No.	Name	Input value	Unit	Set value	Min
Pn000	Basic Function Select Switch 0	0001H	-	-	-
Odigit	Direction Selection	1 : Sets C	\$ 1 433	140	(1 3)
1 digit	Reserved (Do not change.)	0: Reserv	340	3122	242
2digit	Reserved (Do not change.)	0: Reserv	20	8 <u>8</u> 8	20
3digit	Reserved (Do not change.)	0: Reserv	170	-	-
Pn001	Application Function Select Switch 1	0000H	3.53	1 7 5	3.73
Odigit	Servo OFF or Alarm G1 Stop Mode	0 : Stops t		100	1.0
1 digit	Overtravel (OT) Stop Mode	0:Same s		1.00	-
2digit	AC/DC Power Input Selection	0 : Not ap	-	(14)	(-)
3digit	Reserved (Do not change.)	0: Reserv	3 4 3	(1)	420
Pn002	Application Function Select Switch 2	0001H	926	31 <u>4</u> 2	3 <u>1</u> 23
Odigit	Torque limit Option for Command-Option module	1 : The tor	22	-	23
<					>
C Select All(All co	nstant number:include not displayed)			_	🗸 Edit
	Compare			Read	Write

3.2.2 Configuring a Yaskawa $\Sigma V / \Sigma V II$ Drive for use with a Galil EtherCAT Master

This section will outline the steps necessary to configure a Yaskawa $\Sigma V/ \Sigma VII$ drive to operate with a Galil EtherCAT Master from factory default settings. All parameter editing listed in the



following steps is done from the Parameter Editing Window shown in Figure 8

1 Set Rotary Switches

•

Set the drive's Station ID using the two rotary switches located on the drive. This number is the address the EtherCAT Master will use to communicate with the drive. Each drive on the network should have a unique address to avoid communication conflicts.

2 Set Drive Polarity

The Yaskawa ΣV and ΣVII motor/encoder polarity can be configured by setting digit 0 of the Pn000 parameter. By default, Pn000 digit 0 is set to 0. In this configuration, the motor will rotate counter clockwise when a forward move (counts increasing) is issued. Setting Pn000 digit 0 to 1 will reverse the motor/encoder polarity, defining a forward move as a clockwise rotation. Valid values are listed in Table 9.

Pn000 digit 0 value	Forward (counts increasing) direction of rotation
0 (Default)	Counter Clockwise
1	Clockwise

Table 9: Pn000 digit 0 parameter values

3 Set Encoder Resolution

The Yaskawa ΣV drive's default resolution is 2²⁰ counts per revolution. The ΣVII drive's default encoder resolution is scaled internally to 2²⁰ counts per revolution as well. The encoder resolution for both drives can be scaled down if necessary¹. This is done by setting the PnB02 parameter, see Figure 11. Equation 1 lists the formula for changing the Yaskawa $\Sigma V/ \Sigma VII$ drive's encoder resolution.



¹ If using the ΣV in Cyclic Synchronous Torque Mode (MT11) on the DMC-500x0, it is necessary to scale down the encoder resolution to account for the DAC resolution of the drive.

4 Limit Switches

In order to provide the Galil EtherCAT Master access to the Yaskawa $\Sigma V/ \Sigma VII$ drive's limit and home switches, the drive's local input switch functions must be disabled. To do this, two parameters need to be changed on the Yaskawa $\Sigma V/ \Sigma VII$ drive. These values are shown in Figure 10 and Figure 9. Pin outs for the various IO can be found in Section 7.1.2.

5 Home Switch and Hardware Latch

To give the Galil EtherCAT Master access to the home switch and hardware latch on the Yaskawa $\Sigma V / \Sigma VII$ drive, digits 2 and 3 of the Pn511 parameter must be set. Digits 0 and 1 are unavailable to the EtherCAT Master. The settings for digits 2 and 3 are shown in Figure 12. Pin outs for the various IO can be found in Section 7.1.2.



6 Set Position Error Alarm Level

In order to take advantage of the Galil EtherCAT Master's position error commands and subroutines, the Yaskawa $\Sigma V / \Sigma VII$ drive must be configured to ignore its internal error limit. Since SigmaWin+ does not allow this function to be disabled, setting the corresponding parameter to its maximum value ensures position error handling is processed by the Galil EtherCAT Master. To do this, set the Pn520 parameter to its maximum value of 1,073,741,823 as shown in Figure 13.

9		Galil Motion Control
	Pn520 Excessive Position Error Alarm Level Input value 1073741823 → reference units (1 - 1073741823) OK Cancel Figure 13: SigmaWin+ Pn520 selection box	

7 Apply Parameters to the Drive

Click the 'Write' button to write the parameters to the Yaskawa $\Sigma V/$ ΣVII drive's volatile memory.

A verification window will appear showing the parameters that have been changed, and will be written to the drive, click 'OK'. Once the write is complete, cycle the power to the drive for the changes to take effect.

The drive is now configured to communicate with a Galil EtherCAT Master.

Write

non-

3.3 LS Mecapion Pegasus and L7NHA Servo Drive Series

The LS Mecapion Pegasus series is an integrated motor and drive package meaning there is minimal wiring required. The L7NHA Series is capable of interfacing with multiple motor types and vendors.

3.3.1 Resetting the Drive to Factory Defaults

1 Install Drive CM and USB Drivers

Install the most recent version of the DriveCM (Drive Configuration Manager) software and install the recommended USB driver

2 Connect to the Drive

Connect the drive to the PC via mini USB Cable and open DriveCM. Make sure that 'USB' and 'PEGASUS' or 'L7NHA' PEGASUS - PEGAS

3 Load Default Settings

Click the 'Object Window shown in Figure

Dictionary' icon to bring up the Object Dictionary Editor 14.

In order to restore the drive to its factory default settings, Index 0x1011 must be set to the value listed in Table 10.





Input #PolarityAssignmen1HighNot2HighNot3HighNot3HighProbe 2Table 11: DriveCM Digital Input Settings for LS Mecapion Pegasus DriveClick the 'Save toImage: Memory' iconThe new settings willMemory' iconThe new settings willtake effect once the drive has been power cycled.The drive is now configured to communicate with a Galil EtherCAT Master.
Imput #PolarityAssignment1HighNot2HighNot2HighNot3HighNot3HighProbe 2Table 11: DriveCM Digital Input Settings for LS Mecapion Pegasus DriveClick the 'Save toImput Settings for LS Mecapion Pegasus DriveClick the 'Save toImput Settings for LS Mecapion Pegasus DriveClick the 'Save toImput Settings for LS Mecapion Pegasus DriveClick the 'Save toImput Settings for LS Mecapion Pegasus DriveThe new settings willMemory' iconTake effect once the drive has been power cycled.The drive is now configured to communicate with a Galil EtherCAT Master.
1 High Not 2 High Not 3 High Not 4 High Probe 2 Table 11: DriveCM Digital Input Settings for LS Mecapion Pegasus Drive Click the 'Save to Image: Settings will Memory' icon The new settings will take effect once the drive has been power cycled. The drive is now configured to communicate with a Galil EtherCAT Master.
2 High Not 3 High Not 3 High Not 4 High Probe 2 Table 11: DriveCM Digital Input Settings for LS Mecapion Pegasus Drive Click the 'Save to Image: Solution of the new settings will Memory' icon The new settings will take effect once the drive has been power cycled. The drive is now configured to communicate with a Galil EtherCAT Master.
3 High Not 4 High Probe 2 Table 11: DriveCM Digital Input Settings for LS Mecapion Pegasus Drive Click the 'Save to Image: Settings will Memory' icon The new settings will take effect once the drive has been power cycled. The drive is now configured to communicate with a Galil EtherCAT Master.
4 High Probe 2 Table 11: DriveCM Digital Input Settings for LS Mecapion Pegasus Drive Click the 'Save to Image: Click the 'Save to Image: Click the 'Save to The new settings will Memory' icon Take effect once the drive has been power cycled. The drive is now configured to communicate with a Galil EtherCAT Master.
Table 11: DriveCM Digital Input Settings for LS Mecapion Pegasus Drive Click the 'Save to Image: Memory' icon The new settings will take effect once the drive has been power cycled. The drive is now configured to communicate with a Galil EtherCAT Master.
Click the 'Save to The new settings will take effect once the drive has been power cycled. The drive is now configured to communicate with a Galil EtherCAT Master.
The new settings will take effect once the drive has been power cycled. The drive is now configured to communicate with a Galil EtherCAT Master.
The drive is now configured to communicate with a Galil EtherCAT Master.

3.4 Delta ASDA A2-E Servo Drive Series

3.4.1 Resetting the Drive to Factory Defaults

1 Install ASDA-Soft Communication Software and USB Communication Drivers

2 Connect to the drive via USB-B cable

3 Open the Parameter Editor Window

Under the 'P2-XX' Tab in the Parameter Editor Window Tab, double click on the 'Value' field to the right of the 'P2-08' Parameter and set the value to 10. Click the 'Write to Servo' button and power cycle the drive for the changes to take effect.



3.4.2 Configuring a Delta ASDA A2-E Drive for use with a Galil EtherCAT Master

1 Configure IO

•

Under the 'P2-XX' tab in the Parameter Editor Window shown in Figure 17, set each of the parameters listed in Table 12 to the values shown.

1 🛛 🖉 🕹	🖳 🛕 🔂 🛛	🖬 🗶 🐣 📕	🕗 🕄 🚏 🛑 on lin	E			080			
0		P	arameter Editor1 : [/	ASDA-A2-E Servo]	From Drive					
🗃 🔡 👘		🔲 84	8 💁 🖉							
PO-XX P1	- XX P 2 - XX	P3-XX P4	-XX P5-XX P6-X	X P7-XX						
V 1 643		Value	∗ Unit Min	Max In	efault Description		^			
P2 - 01	PPR	100	% 10	500 1	00 Switching Bate of Positi	ion Loop Gain				
P2 - 02	PFG	50	% 0	100 5	0 Position Feed Forward	Gain				
P2 - 03	PFF	5		F	Parameter Setting Helper		_ 🗆 🗙			
P2 - 04	KVP	500	Daramotor Hama	Unit	Minimum et Maximum	Dofault	16/22 bit			
P2 - 05	SPR	100	Parameter Name	UNIC	Minimum ~ Maximum	Default	10/32 DIC			
P2 - 06	KVI	100	P2 - 13		0x0000 ~ 0x015F	0x0124	16bit			
P2 - 07	KVF	0								
P2 - 08	PCTL	n DI4 Functional Planning								
P2 - 09	DRT	2		Va	alue 0x0000					
P2 - 10	DI1	0x0100	-							
P2 - 11	DI2	0x0100	-							
P2-12	DI3	0x0100	-							
P2-13	DI4	0x0000	-							
P2 - 15	DIS	0x0000		X : Functional Setting	[0x00]Disabled		✓			
P2 - 16	DIZ	0x0000	-							
P2 - 17	DI8	0x0100								
P2 - 18	DO1	0x0101								
P2 - 19	DO2	0x0100			2: Input Contact					
P2 - 20	DO3	0x0100		(Inormally closed (contact b)					
P2 - 21	DO4	0x0007			[1] : Normally opened (contact a)					
P2 - 22	DO5	0x0100								
P2 - 23	NCF1	1000								
P2 - 24	DPH1	0								
P2 - 25	NLP	0.2			Cancel OK	-Write to	Serve			
P2 - 26	DST	0	-	L			_~			
<							>			
★ Read-On	ly	Set When	Servo OFF 🛛 🔴 Valio	d After Re-power on	Volatile Parameter	Parameter for three	axes			
Firmware Version:	1.643.366		N	ote: Double-click the	Value can be call out the Parameter	Setting Helper				

Parameter	Name	Functional State	Input Contact
P2 - 13	DI 4	Disabled	Normally Closed
P2 -14	DI 5	Disabled	Normally Closed
P2 -15	DI 6	Disabled	Normally Closed
P2 -16	DI7	Emergency Stop*	Normally Open
P2 - 40	EDI13	Disabled	Normally Closed

Table 12: ASDA Soft IO Parameter Configuration Values

To enable IO over EtherCAT, under the 'P3-XX' Tab, set parameter 'P3-18' to 0x1000. Pin outs for the various IO can be found in Section 7.1.8.

Power cycle the drive for the changes to take effect.

I IIII

The drive is now configured to communicate with a Galil EtherCAT Master.

3.5 Panasonic Minas A5B Servo Drive Series

The Minas-A5B Servo Drive provides EtherCAT Communication and high resolution encoder feedback in one drive/motor package.

3.5.1 Resetting the Drive to Factory Defaults

1 Install Panaterm Software and Connect to the Drive

Install the Panaterm Software on a Windows machine and connect to the Minas A5B drive via mini USB cable. The Panaterm Connection Window is shown in Figure 18.

Selection of the Communica Communic V Series	communication with ation with the driver cate with driver direc automatic decision	n the driver	with USB.		OK Cancel
Drive Series Name MINAS-A5B	Drive Product No MADHT1507B01	Drive Serial No 13120006	Motor Product No MSMD022G1S	Motor Serial No 14010005	Check Update
O No commun Execute th communic	nication ne command such a ating with the driver	is parameter fili	ng with PC withou	t	

2 Reset the Drive to Defaults

From the main menu bar, navigate to 'Parameter -> Read the default' to open the parameters window.

In the parameters window menu bar, select the 'Trans' button to transmit the default parameters to the drive.

After transmitting, click the 'EEP' Icon to write the parameters to the

drive's EEPROM.

3.5.2 Configuring the Panasonic Minas A5B Drive for Use with a Galil EtherCAT Master

Figure 19 shows the Parameter Editing Window. The drop down menu to the left will be used to navigate to and set the following parameters.

Read	Save	Cmnt	D. Rcv	Trans	Pr	nt Exit	EEP Scree	en Comp	D. Initial	B	iin/Hex		
^o ositio ∎ ∙Initia	n control ally(Positio	n)	•	By the s the relate select th each sul after the	electing ed parar e "Parar o-theme input. A	the theme from the left neters can be displayed meter list". Please doub . Parameter value can b nother way to click <ch< td=""><td>above, and se I. To display al le-click the sub le changed in t ange of set val</td><td>lecting the su II parameters b-theme left b wo ways. One ue> button.</td><td>b-theme fror in numerical elow to refer e way to pres</td><td>n the le order, the de ss the</td><td>eft below, please trails of Enter key</td><td>Char \</td><td>nge of set value</td></ch<>	above, and se I. To display al le-click the sub le changed in t ange of set val	lecting the su II parameters b-theme left b wo ways. One ue> button.	b-theme fror in numerical elow to refer e way to pres	n the le order, the de ss the	eft below, please trails of Enter key	Char \	nge of set value
				Class	No.	Parameter nan	ne	Setup	range		Set value		Unit
				00	001	Control mode setup		0-	-	6	0:Semi-closed	•	
				00	002	Real-time auto tuning	setup	0-	-	6	1:Standard	-	
				00	003	Machine stiffness at re	al-time	0-	-	31		13	
				02	000	Adaptive filter mode s	etup	0-	-	4	0:Invalid	-	
				Selects t	ne contr	ol modes.							
					_		_						
				Read O	nly	NotUse	Res	set .		Can ov	vervalue		

1 Motor Polarity

•

In the drop down menu, select 'Revolution direction Setting'. The parameter 'For manufacturer's use' can be set to either 0 or 1 depending on application requirements. The behavior for each value is detailed in Table 13

Value	Function
0	A positive move (counts increasing) will rotate the motor Clockwise (CW)
1	A positive move (counts increasing) will rotate the motor Counter Clockwise (CCW)

Table 13: Revolution Direction Settings

2 Disable Drive Position Error Monitoring

Select 'Protection level setting function' in the column below the 'Function by Function' drop down menu. Change the 'Position deviation excess setup' parameter's set value from 10000 to 0, this will disable this parameter.

3 Disable Drive Speed Monitoring

Change the 'Speed deviation excess setup' parameter's set value to 0, this will disable the drive's speed monitoring function.

4 Set Encoder Resolution

•

In the main tool bar select 'Other' and click on 'Object Editor'. This will open the Object Editor Window shown in Figure 20. In the object tree to the left, select the '6000h' object. Scroll down and select the 'Feed' object. The Default for this setting is 2²⁰ (4294967295). The 'setting value' for this parameter will allow you to set the number of encoder counts per revolution for your motor. Set it to a value appropriate for your application.

ead Save	Cmnt	Rev	v Tra	ns EEP	Exit Scre	en	Disp Se	lect Hex 💌			
ESM state is not I nject 3000h group nject other than th Close TreeView	nit th value e 300	en, you w e can be o 10h group PDS	vill not b changed can en Condit	e able to do the s press the Enter H able If you reset t	end to the driver Key or click <ch he control power to switch on</ch 	and char ange of s after wri	nging the set value iting the l	setting value. > button. EEPROM. SM Condition	IIT	Change val	e of set ue
All object		Main Index	Sub Index	Object Name		Data Type	Attrib	Min - Max		Setting Value	Units
- 1000h		1000h	00h	Device type		U32	RO	00000000h-	FFFFFFFh	00020192h	
- 1A00h		1001h	00h	Error register		U8	RO	00h-	FFh	00h	
- 1C00h		1008h	00h	Manufacturer de	vice name	VS	RO	-		MADHT1507B01	
🖃 3000h		1009h	00h	Manufacturer ha	rdware version	VS	RO	-		V1.00	
- 3000h		100Ah	00h	Manufacturer so	tware version	VS	RO	-		V1.00	
- 3100h		1010h	00h	Number of entrie	S	U8	RO	00h-	FFh	01h	
- 3200h		1010h	01h	Save all parame	ters	U32	RW	0000000h-	FFFFFFFh	0000000h	
- 3400h		1018h	00h	Number of entrie	S	U8	RO	00h-	FFh	04h	
- 3500h		1018h	01h	Vendor ID		U32	RO	0000000h-	FFFFFFFh	0000066Fh	
- 3600h		1018h	02h	Product code		U32	RO	0000000h-	FFFFFFFh	51507001h	
-3700h		1018h	03h	Revision numbe	r	U32	RO	0000000h-	FFFFFFFh	00010000h	
- 3800h		1018h	04h	Serial number		U32	RO	0000000h-	FFFFFFFh	13120006h	
Extraction		10F3h	00h	Number of entrie	S	U8	RO	00h-	FFh	13h	
274 2000		10F3h	01h	Maximum messa	ages	U8	RO	00h-	FFh	0Eh	
		10F3h	02h	Newest messag	e	U8	RO	00h-	FFh	00h	
	15	10F3h	03h	Newest acknow	edaed mess	1.18	RW	00h-	FFh	POP POP	

5 Configuring I/O

Select the 'Display D' drop down menu in the main toolbar, and click 'Pin Assign R'. This will bring up the 'Pin Assign' window. Set the values for the pins listed under 'Input' as shown in Table 14. Pin outs for the various IO can be found in Section 7.1.10.

Pin Number	Position/Full-Closed Control	Velocity Control	Torque Control
07 (SI2)	SI-MON3_ConnectA	Invalid	Invalid
08 (SI3)	SI-MON4_ConnectA	Invalid	Invalid
10 (SI5)	SI-MON5_ConnectA	Invalid	Invalid
11 (SI6)	EXT2_ConnectA	EXT2_Connec tA	EXT2_ConnectA

Table 14: Panaterm Digital IO Settings

6 Saving Configuration to Memory

After setting all required parameters, transmit them to the drive by clicking the 'Trans' icon. \prod_{Trans}

Write the parameters to the drive's non-volatile memory by clicking the 'EEP' icon. Power cycle the drive for the changes to take effect.



9		Galil	Motion	Control
	The drive is now configured to communicate with a Galil EtherCAT	Master.		

3.6 Copley Xenus Plus Servo Drive Series

This section will detail the process of both resetting and configuring a Copley Xenus Plus XEL-230-36 drive to operate with a Galil BLM-N23-50-1000-B 3-phase brushless motor, hereafter referred to as a Galil BLM.

3.6.1 Resetting the Drive to Factory Defaults

1 Install CME 2 and Connect to the Drive

•

Install the Copley CME 2 Software on a Windows machine and connect to the drive via the Copley Serial to RJ45 communications cable. If using Windows 7 or 8, Copley advises installing and running CME 2 as Administrator to allow access to COM ports.

In the main menu bar, navigate to Tools -> Communication Wizard to configure the Serial Communications Port. Once communications are correctly configured, the drive should be listed in the 'Copley Neighborhood' menu.



2 Save Drive Default Values to File

Select the 'Virtual Amplifier' item in the 'Copley Neighborhood' window. Ignore prompts to save data before switching to the Virtual Amplifier and select 'Create new amplifier file' in the 'Open Virtual Amplifier' Window shown in Figure 22.

Choose the method you want to use to create the virtual amplifier.
Create new amplifier file
Open existing amplifier file
OK Cancel Help
Figure 22: Copley CME 2 Virtual Amplifier Window

Select the 'XE2_XenusPlusEtherCAT.ccv' file and save it as 'XE2 Default Settings.ccx' click the 'Cancel' button in the 'Basic Setup Axis A' prompt that follows.

The drive's default configuration values have now been saved to an amplifier configuration file

that can be downloaded and saved to the amplifier.

3 Save Default Values to the Drive

With the Drive selected in the 'Copley Neighborhood' menu, navigate to File -> Restore -> Amplifier Data. Select the 'XE2 Default Settings.ccx' file that was saved in step 2.

Now click the 'Save Working Memory to Flash' icon.

Power cycle the drive for the changes to take effect.

3.6.2 Configuring the Copley Xenus Plus Drive for use with a Galil EtherCAT Master

1 Configure IO

•

In the Main Configuration Window, click on the This will bring up the IO Configuration Window shown in Input/Output Button.

Figure 23.

Input / Output

Digital Inputs 1-6 Digital Inputs 7-14	Digital Outputs Analog IO				
			Debounce	time	
○ Pull up +5V ● Pull down [IN1]	Not Configured	~	0	ms	Lo
Pull up +5V Pull down [IN2]	High Speed Position Capture on HI-LO Transition	~	0	ms	н
Pull up +5V Pull down [IN3]	Not Configured	¥	0	ms	н
$\textcircled{\sc 0}$ Pull up +5V \bigcirc Pull down [IN4]	Not Configured	~	0	ms	н
Pull up +5V Pull down [IN5]	Not Configured	*	0	ms	н
○ Pull up +5V	Not Configured	~	0	ms	Lo
Figure 23: Con	lev CME 2 10 Configurat	tion V	Vind	Ιον	1

Values for Digital Inputs 1 - 6 are shown in Table 15.

Input	Polarity	Setting
[IN1]	Pull up	Not Configured
[IN2]	Pull up +5V	High Speed Position Capture on HI-LO Transition
[IN3]	Pull up +5V	Not Configured
[IN4]	Pull up +5V	Not Configured
[IN5]	Pull up +5V	Not Configured
[IN6]	Pull Down	Not Configured

Table 15: Copley CME 2 Digital Input Settings

Pin outs for the various IO can be found in Section 7.1.6.

Setup Motor Parameters for Galil BLM In the Main Configuration Window, click on the Motor/Feedback This will bring up the Motor/Feedback Window. When using the Galil BLM, enter the values pictured shown in Figure 24 . These values can also be found in the Appendix on page 60. Motor Feedback Brake\Stop Manufacturer: Galil -Units Metric English Model Number: BLM Motor Inertia: 0.25 kg·cm² v Torque Constant: 0.08 N·m/Apk Number of Poles: 4 ~ Back emf Constant: 9.8 V/krpm Peak Torque: 0.83 N·m 🗸 Resistance 1.2 ohms Continuous Torque: 0.39 N·m 🗸 Inductance: 2.6 mH Velocity Limit: 5000 rpm 🖓 🖓 🂭 🦛 Calculate OK Cancel Figure 24: Copley CME 2 Motor/Feedback Window Once these values have been entered, click the 'Calculate' Button. Calculate This will populate the amplifier's current loop values appropriate for the specified motor. Click OK to close the window and save the parameters to the drive's flash memory. Calibrate Motor for Commutation window toolbar. Click the Auto Phase Icon in the main Follow the instructions detailed by the pop up windows to set up the amplifier for sinusoidal commutation of the Galil BLM. This procedure will apply power to the motor and cause it to rotate Warning one revolution. Be sure that the motor is secured and uncoupled from any mechanics. Click the 'Save Working Memory to Flash' Icon. Power cycle the drive for the changes to take effect. The drive is now configured to communicate with a Galil EtherCAT Master.

Galil Motion Control

•

2

3

Motor/Feedback Button.

3.7 Sanyo-Denki R Advanced Servo Drive

3.7.1 Resetting the Drive to Factory Defaults

1 Install R ADVANCED MODEL Setup Software and Connect to the Drive

Install the software R ADVANCED MODEL Setup Software on a Windows PC. Using the serial cable specified by Sanyo-Denki, connect the drive to the PC and launch the R ADVANCED MODEL application. When the application launches the 'Communications Setting' dialog box will appear, see Figure 25.

Check the 'Selection' box and choose the correct COM port and Baud Rate (38400 bps) then

~	9	1	COM8	v	38400bns	v	Connect
		2	00110		00400000		Connect
		3		V		~	Connect
		4		\sim		~	Connect
	•	5		\vee		~	Connect
		6		\vee		~	Connect
		7		\sim		~	Connect
		8		\sim		\sim	Connect
		9		\sim		~	Connect
	۲	А		\sim		~	Connect
	۲	В		\sim		~	Connect
	•	С		\sim		\sim	Connect
	•	D		\sim		~	Connect
	•	Е		\sim		\sim	Connect
	۲	F		\sim		\sim	Connect

click 'Connect'.

2 Load Default Settings

 The non-volatile memory on the R Advanced Drive contains a section for parameter
 backup and restoration. However this section is not write protected. Therefore, Sanyo-Denke strongly recommends saving this initial configuration to a back up file on the PC before changing any parameters.

In the main menu bar, navigate to Parameter -> Parameter Transmission (To File)

In order to copy parameters from a file to the drive: In the main menu bar, navigate to Parameter -> Parameter Transmission (To Amplifier)

Use the 'Save to the Backup Memory' and 'Restore from the Backup Memory' menu items to write parameters to the drive's back up memory space or copy parameters from it.

I all a construction of the second se

3.7.2 Configuring the Sanyo-Denke R Advanced Drive for Use with a Galil EtherCAT Master

1 Connect to the drive and open the Parameter Editing Window

From the main menu bar, select Parameters -> Parameter Setting to bring up the editing window shown in Figure 26

	8		Paramet	ter Sett	ing(Axis1)			
ion Level	File(F) Amplifier(A) Disk(D) Password	Setting(P) Ampli	ifier Infor	mation(l)			
s1[]	i 1 🛛 🖓 🖓 🖉) 🔊 🖬 🕅						
ile	Amplifier /Mator Model		24 4000105					
	Motor Combination	N32AU 1A2RAS	270106010F	System	Information			
	Present Setting Value	R2AA06010F(110C-0184)		Jyacon	Motor Structure	00:ROTARY		
	Input Value				Main Power Supply	00:200V		
				Am	plifier Capacity Code	0C:15A		
	Select from the list(M) Automatic Setup (Re	commendation)(S)		Control Board Code	32:P1TYPE_3	2	Edit(E)
	Group A [Profile Positio	n/Interpolated position] Gr	oup B [Sequence]	Group C [E	Encoder/Alam] Gro	up D[Homing/Op	xtionCode]	
	System Group 0 (Aut	o-tuning] Group 1 [Basic G	ontrol] Group 7 [Con	nmunicatio	on/Display] Group 8	[Control] Grou	ip 9 (Function / C	Output Select]
	ID Symbol	Name	Present Setting	Unit	Input Value	Minimum	Maximum	Standard
	• 01 0:20FD 2	Man Crout nower input Typ	e 01040_single-p			-	-	00/AC_3/phase
	• 02 0-2005-M	negenerative mesistor sele	. UT:BUIKIN_N	-		- 0000		UT:built-In_R
	* 02 0x20FE 1/E	Combined motor code	0104			0000	CCCC	CCCC
	* 04 0x20FE 2:E	Combined sensor tresolution .				0000	CCCC	CCCC
	* 07 0x20E2.1-P	Position Control Selection	00-Standard	Ċ.				00-Standard
	• 09 0v20E2.2-P	Position Loop Control Positi	00-Mater Eco	Ê.				00:Mater Epo
	• 09 0x20FE.2-E	External Pulse Eccoder Res.	2000	- D/D		- 500	- 00000	2000
	00 0.2011-0.2	Datemar 1 and Encoder 1165.		100		500	33333	2000
	When the data of the he	ad * mark is changed, it beco	mes effective after po	wer supply	yre-input.			

2 Set Motor Polarity

Select the Tab labeled 'Group 8 [Control]' and set the first object (Polarity)

3 Configure IO

•

Select the Tab labeled 'Group 9 [Function / Output Select]' and ensure that the functions listed in Table 16 are set to '00 Always Disabled'. Pin outs for the various IO can be found in Section 7.1.7.

Name	Input Value
Positive Limit Switch Function	00 Always Disabled
Negative Limit Switch Function	00 Always Disabled
Main Power Discharge Function	00 Always Disabled (this is required to support hardware latching)

Table 16: IO Settings for Sanyo-Denke R Advanced Drive

9		Galil Motion Control
Click the 'Write in Amplifien Power cycle the drive for th The drive is now configured	r' Icon to save the changes to the he changes to take effect. d to communicate with a Galil Ethe	drive's EEPROM.

3.8 Parker PD-10C Servo Drive Series

3.8.1 Resetting Drive to Factory Defaults

1 Install Drive Support Tool and USB Drivers

Install the most recent version of the Drive Support Tool software and install the recommended USB driver.

2 Connect to the Drive

- a) Ensure that all motor and encoder wiring is complete as per the Drive's User Manual.
- b) Install Parker's Drive Support Tool Software and USB drivers provided on the manufacturer's website.
- c) Connect the drive to the PC via USB Cable and provide power to the drive.
- d) Start the Drive Support Tool software, and configure communications as shown in Figure 27.
- e) Click the
- button to transition from 'Offline' to 'Online'.



f) A 'Drive Information' Dialog box will appear shown in Figure 28. Close this window to continue.

Drive Family	PD-10C	
Software Version	0.81	
Bootloader Version	0.05	
FPGA Version	0.10	
Drive Rated Current	6.7	Arms
Node Address	1	
User Drive Name	Drive	Save

Ŷ

9	Galil Motio	on Control
3	Load Default Settings a) Select the 'Setup' Toolbar and select 'Return to Factory Set' as shown in $\underbrace{\boxed{\texttt{Drive Support Tool - Parker Hannifin EM}}_{Drive Motor I/O Fault Monitoring Procedures Advanced Indexer Object Dictionary Setup AboutConfigurationFirmware Update$	Figure 29.
	Quick Setup Display Theme Setup Wizard Display Theme Auto Motor Phasing Figure 29: Parker PD-10C Return to Factory Set	
3.8 Etł 1	 b) A dialog box will appear asking to confirm reset of all parameters to factor click 'OK'. Once the drive has been reset, power cycle the drive and records. B.2 Configuring the Parker PD-10C EtherCAT drive for use wherCAT Master Setup Wizard a) Click on th setup Wizard b) A dialog box will ask to read the parameters from the drive, click 'Yes'. One parameters from the drive, click 'Yes'. 	ory setting, nnect. r ith a Galil he Setup ce the Drive
	Setup Wzard Investigation of the content of the content of the use	
Galil <u>E</u>	Figure 30: Parker PD-10C – Launching Setup Wizard	36

•		Galil Motion Control
	c)	Motor & Encoder Setting (Page 1/3) - For the Motor Selection Page select 'Smart
		Setup Wirad Image: Setup Wirad Drive Selection Protection Hotor & Incoder Setting Image: Setup Wirad More ID Image: Setup Wirad More ID Image: Setup Wirad Control Mode Setting Image: Setup Wirad Motor ID Image: Setup Wirad Control Mode Setting Image: Setup Wirad Reference Index Image: Setup Wirad If yo Signal Setting Image: Setup Wirad Image: Setup Wirad Image: Setup Wirad
	d)	For the 'General Setting (Page 1/7) Rotation Direct Select' page, select 'CW rotate by positive command CCW rotate by negative command' as shown in Figure 7. Click 'Next' to continue.
		Setup Wizad Drive Selection Po-Joc Motor B: B55 setal aboute(find)thum 18(c) B55 setal aboute(find)thum 18(c) <
Galil	- - the	rCAT Master Setup Guide Rev 1.0d 37



pate of the	
PD-10C	General Setting (Page 6/7) : Set un Torque Limit Function
Motor & Encoder Setting	
Motor ID : BiSS serial absolute(multi-turn 16bit) Resolution : 524288 pulse/revolution	Jou can initial output I orque to protect machinery, please set up "Torque Limit Function" to do this. Z. Set up Torque Limit Value.
Control Mode Selection	Torque Limit Function
Not Supported	
Reference Input Setting	Internal torque limit 1 External torque limit
General Setting CW rotate by positive command Electronic Gener Ratio = 1/1 Using emergency stop torque : 100 [%] Dynamic Break -> Stop -> Hold	External Positive Torque Limit Value 3000 0.1%
I/O Signal Setting	Torque Input
Homing Method Setting	External negative Torque Limit Value 30000 0.1%
Save & Write	

- j) For 'General Setting (Page 7/7) Set up signals related with control', leave the default values selected and click 'Next'.
- k) For the Input/Output Setting, set all of the Digital Inputs as shown in Figure 10. Click 'Next' when values have been set. Pin outs for the various IO can be found in Section 7.1.9.

Abor ID : BicS serial absolute(multi-turn 16bit)	Input/Output Signal Setting 1. Set up the Level of In/Output signals High(A): this is A contact(Normal-off), basic status is High(1) Level state Low(B): this is B contact(Normal-on), basic status is Low(0) Level state. 2. Allocate the functions of In/Output Signals according to each contacts.
Resolution : 524288 pulse/revolution Control Mode Selection Not Supported	Digital Input Digital Output Analog Monitor
Reference Input Setting Vot Supported General Setting CW rotate by positive command Electronic Gear Ratio = 1/1 Using emergency stop torque : 100 [%6] Dynamic Break -> Stop -> Hold External torque limit I/O Signal Setting Homing Method Setting	Input 1 rtCH Not Assigned - Input 2 rtCH Not Assigned - Input 3 rtCH Not Assigned - Input 4 COW PROBE2 - Input 5 rtCH Not Assigned - Input 6 rtCH Not Assigned - Input 7 rtCH Not Assigned - Input 8 rtCH Not Assigned -
Save & Write	< <u>Back</u> <u>Next</u> > <u>D</u> one
Fi	igure 35: Parker PD-10C – I/O Configuration

•

settings have been w or Power Re-cycle to	apply changes". Click 'Ok' to continue.
Setup Wizard	
Drive Selection	File Store. Write into the drive
PD-10C	1. "Save to File" Button stores current setting values to file(.cfg).
Motor & Encoder Setting Motor ID : BISS serial absolute(multi-turn 16bit) Resolution : 524288 pulse/revolution	 "Write to Drive" Button transfer current setting values to drive and store to memory. (This is activated when drive is connected with communication normally. Also please reset SW or switch on/off Power.)
Control Mode Selection	
Reference Input Setting	
Not Supported	
	Information X
General Setting	Required to Software Reset or Power re-cycle to apply
Electronic Gear Ratio = 1/1	Changes.
Dynamic Break -> Stop -> Hold	OK Switte to Drive
I/O Signal Setting	
Input : Custom setting	✓ USB : On-Line
Homing Method Setting	
34: move+, index pulse	
Save & Write	
	< <u>B</u> ack <u>N</u> ext > Use Cose

 n) Close the setup wizard, click 'Yes' when prompted to exit. Now click the 'Software Reset' button in the Drive Support Tool menu. Click 'Yes' when prompted to software reset the drive. During this process connection the drive will be lost. Once the drive's LCD shows '-.66' power cycle the drive.

The drive is now ready to use with a Galil EtherCAT Master.

If desired the settings can be confirmed by connecting to the drive with Drive Support Tool, and running through Setup Wizard again. The values in the Wizard should reflect the values that were set in this procedure.

3.9 Estun ProNet Servo Drive Series

•

The Estun ProNet Servo Drive provides two means of initialization, either through the ESView Software or the operator panel located on the front of the drive. This set up guide will detail configuration using ESView Software wherever possible.

This setup guide was written using Estun ESView Software v2.1. Estun provides a USB to RS422 adapter for communication with the Estun ProNet Series Drives.

3.9.1 Resetting the Drive to Factory Defaults

1 Install ESView Software and Connect to the Drive

2 Navigate to the main parameter editing window

Once connected to the drive, open the main parameter editing window, shown in Figure 37. From here, nearly all drive parameters can be set.



3 Click the 'Initialize' Button to reset all parameters to factory defaults.

Click 'OK' when prompted to overwrite all existing parameters and power cycle the drive for the changes to take effect.

3.9.2 Configuring the Estun ProNet Servo Drive for use with a Galil EtherCAT Master

1 Connect to the Drive using the ESView Software and open the Parameter Editor Window.

2 Set Drive Parameters

•

Enter the parameter values listed in Table 17.

Parameter	Value	Function
Pn000.01	1	Disables Forward Limit Switch Handling
Pn000.02	1	Disables Reverse Limit Switch Handling
Pn001.00	1	Sets Clockwise rotation as forward
Pn201	1	Encoder Scaling Numerator
Pn202	1	Encoder Scaling Denominator
Pn509.01	C HmRef	Home Sensor Input
Pn509.02	2 P-OT	Forward Limit Switch Input
Pn509.03	3 N-OT	Reverse Limit Switch Input

Table 17: ESView Parameter Editor Window Values

The effective encoder resolution, the value which will be reported to the Galil via the EtherCAT Network, can be set via the Pn201 and Pn202 parameters and Equation 3. Pin outs for the

Encoder Counts / Revolution = $\frac{Pn201}{Pn202} 2^{15}$ Equation 3: Encoder Scaling Equation for the Estun ProNet Servo Drive

various IO can be found in Section 7.1.10.

3 Configure the Drive for EtherCAT Control

ESView v2.1 does not allow access to the drive parameter setting necessary for EtherCAT Operation. This parameter must be set via the operator panel located on the drive. Instructions on navigating the relevant menu options and setting parameters can be found in the Estun ProNet Drive Series User Manual.

In order to enable operation over EtherCAT, 'Bus Mode' Parameter must be set to the value listed in Table 18.

Parameter	Value	Function
Pn006.0	4	Enable EtherCAT Control

Table 18: Bus Mode Selection Parameter Value

Power cycle the drive for the changes to take effect.

9		Galil	Motion	Control
	The drive is now configured to communicate with a Galil EtherCAT	Master.		

4 Configuring EtherCAT IO

EtherCAT communication with IO hardware is simpler than communication with EtherCAT drives since profiling information is not required. As a result, configuring EtherCAT IO hardware is typically minimal.

4.1 Galil RIO-574x0 EtherCAT IO

For for a complete reference, refer to the RIO-574x0 manual.

4.1.1 Resetting a Galil RIO-574x0

The RIO-574x0 can be easily reset to factory conditions by performing a master reset. This procedure is detailed below:

- 1. Power down the RIO
- 2. Install a jumper on the MR jumper header
- 3. Power on the RIO

•

- 4. Wait for the red ERR LED to turn off
- 5. Power down the RIO and remove the MR jumper

4.1.2 Configuring a Galil RIO-574x0

The RIO-574x0 comes from the factory pre-configured to work with a Galil EtherCAT Master 'out of the box.' No further configuration is necessary. However, the RIO's analog input and output ranges can be configured using Galil Communication Software.

4.2 VIPA EtherCAT IO

Currently the VIPA IO Unit will operate with a Galil EtherCAT Master with no configuration necessary. Galil includes support for specific Digital Inputs/Outputs and Analog Inputs only, see Table 19. The analog inputs are non configurable.

Part #	Description
VIPA 053-1EC00	EtherCAT Communication Module
VIPA 021-1BF00	8 x 24V DC Digital Inputs
VIPA 022-1HB10	2 x 3A Digital Outputs
VIPA 031-1BB70	2 x +/-10V Analog Inputs

Table 19: Supported VIPA IO components

Note

The VIPA IO Module does not include support for Distributed Clock and therefore can not be the first node in an EtherCAT network.

5 Features and Limitations

5.1 General

•

5.1.1 Position Feedback

Upon boot-up, the EtherCAT Master assumes a position of zero on all axes. When an EtherCAT axis is initialized with the EX and EU commands, the position feedback read in from the EtherCAT drive will replace any value currently held by the local main encoder inputs (TP). In addition, the reference position (RP) will mirror the change in TP to prevent any position error (TE) during initialization. After initialization, any commands used to query the position of the motor will report back the EtherCAT drive position data. After an EU0 is issued to turn off the EtherCAT network, the RP and TP values will both be zero.

The CN command will configure logic polarity for local and EtherCAT axes limit switches and hardware latch, active high or active low. However the command does not change the drive's actual limit switch logic. This must be done per the manufacturer's instructions. In addition, the CN command will configure the initial movement direction when the HM command is issued. See the User Manuals and Command References for details on the use of the CN and HM commands.

5.1.2 Limit Switches

After EtherCAT axes have been activated with the EX and EU commands, the EtherCAT Master will report back with the status of the remote EtherCAT drive's forward and reverse limit switch inputs. The status of these inputs can be queried using _LFm,_LRm, TS, and the data record where m is the EtherCAT axis of interest.

The #LIMSWI automatic subroutine and the OE command will both function based on the status of EtherCAT axes limits and position error.

5.1.3 Homing Routines

Homing can be customized using the HM and FI commands. After EtherCAT axes have been activated with the EX and EU commands, the EtherCAT Master will report back the status of the remote EtherCAT drive's home input. The status of the home inputs can be queried using _HMm, TS and the data record where m is the axis of interest.

5.1.4 Configuration Commands

CE configures the local auxiliary encoder on an EtherCAT axis ^{1.}

5.1.5 Non Supported Commands and Error Routines

The following commands are not available for use with an EtherCAT axis and will generate an error. TC1 will return "186 Not available on EtherCAT"

AG, AU, BA, BB, BC, BO, BQ, BS, BX, BZ, OC, QH

The TA command and the #AMPERR routine will only run due to local DMC internal amplifier errors¹. To monitor the status of an EtherCAT drive, the user should use the EU and EZ commands and the #ECATERR automatic subroutine.

¹Applies only to the DMC-500x0

•

5.2 Drive Limitations

5.2.1 Support for Cyclic Synchronous Torque Mode¹

Cyclic Synchronous Torque Mode is only supported on the DMC-500x0 with Yaskawa Sigma 5 and AMC-DZEANTU Drives.

5.2.2 Delta ASD-A2

The Delta ASD-A2 does not include support for the hardware latch. Issuing the AL command will throw error 190, 'Feature not supported by drive.'

5.2.3 Estun ProNet

Hardware latch and latch on index are not supported on this drive. Issuing the AL, ALT, FI or HM commands will throw error 190, 'Feature not supported by drive.'

5.2.4 Sanyo-Denki

Hardware latch is not supported on this drive. Issuing the ALm command will throw error 190, 'Not valid with this motor type.'

5.2.5 Yaskawa Sigma 5

As of EtherCAT Communication Module firmware revision 0006, drive DAC resolution requires scaling encoder resolution when in Cyclic Synchronous Torque mode.¹

¹Applies only to the DMC-500x0

6 DMC Quick Start Guide

Below are a few examples demonstrating the commands necessary to bring up an EtherCAT network and handle possible EtherCAT errors. For more detail on a particular command please see the DMC-500x0 and DMC-52000 Command References. To disable a previously enabled EtherCAT axis¹, issue an MTm=0 for axes E-H, and MTm=1 axes A-D, where m is the axis to be disabled.

6.1 Example 1: Single Axis Position Relative Move

This example demonstrates how to map one axis to an EtherCAT slave and perform a relative move.

#setup

AMA;

EN :

•

```
M0 ; 'turn off all motors
MT 10 ; 'set A axis for position mode
EX -1 ; 'set first ECAT drive as A axis
EU 1 ; 'bring up ECAT network
SH A ; 'servo motor
#move
SP 10000 ; 'set speed
AC 100000 ; 'set acceleration
DC 100000 ; 'set deceleration
PR 10000 ; 'position relative move
BG A ; 'begin motion on A axis
```

'after A axis move

'end program

6.2 Example 2: Four Axes and single IO EtherCAT Network Setup

This example expands upon Example 1 and demonstrates how to setup a 4 axis controller with all 4 axes mapped to EtherCAT slaves. In addition, a single IO Module will also be added to the Network using the IO command. With the MT command set to a value of 10 axes A, B, C, and D will run in position mode.

```
#setup
M0 ; ' turn all motors off
'set axes A,B,C,and D for position mode
MT 10,10,10,10
'Map ECAT drives to local axes using wire position (negative numbers)
'and station ID (positive numbers). $ designates a hex number
EX -1,$5,$C1,-4
'Map IO Module to first IO position using line position
IO -5
EU 1<6000 ; 'bring up the ECAT network with a 6,000 ms timeout
SH ; 'servo all axes
#move
SP*= 10000 ; 'set speed for all axes
AC*= 100000 ; 'set acceleration for all axes
```

Galil EtherCAT Master Setup Guide Rev 1.0d

```
DC*= 100000 ; 'set deceleration for all axes
PR*= 10000 ; 'position relative move for all axes
BG ; 'begin motion on all axes
AM ; 'after move
'Query first Analog Input on IO Module
MG @AN[11001]
EN ; 'end program
```

¹Applies only to the DMC-500x0

•

6.3 Example 3: EtherCAT Error Handling

This example demonstrates use of the #ECATERR automatic subroutine which will run if there is an error reported by any EtherCAT drive on the network. The EZ command will print the error to the user in a table which will contain all the drive error information. See Appendix 7.2.2 for more detail on the EZ command.

```
'Galil DMC Code Example
' assumes that the AMC drive is on the A axis and in
'position 1 and the Yaskawa drive is on the B axis and in position 2
#setup
ST
AM
MO
EU 0
MT 10,10
EX -1,-2
EU 1
#move
SH AB
JG 1000,2000
BG AB
ΕN
#ECATERR
EZO; ' query drive faults
JS #amcerr, (_EU1 & $0001)
JS #yaserr, (_EU1 & $0002)
EU 0; 'turn off EtherCAT network
RE; 'Exit routine and return to main code execution
'Subroutine to handle an AMC drive Hall Error on the A axis.
#amcerr
IF (_EZA2 = 4);' check for specific AMC hall error
 MG "Hall Error on A Axis AMC Drive"
ENDIF
FN
#vaserr
IF ( EZB0 = $0C90);' check for specific Yaskawa error
 MG "Encoder Error on B Axis Yaskawa Drive"
ENDIF
EN
```

7 Appendices

7.1 I/O Pin Outs

•

7.1.1 AMC-DZE P7 I/O Connector

Name	Pin #	Galil Function	Description
PDI-1	3	Forward Limit Input	Indicates when the forward travel limit sensor has been activated
PDI-2	5	Reverse Limit Input	Indicates when the forward travel limit sensor has been activated
PDI-3	7	Home Sensor Input	Indicates when the Home Sensor has been activated
PDI-4+	4	Index input +	High speed differential input +
PDI-4-	6	Index input -	High speed differential input -
PDI-5+	8	Latch input +	High speed differential input +
PDI-5-	10	Latch input -	High speed differential input -
+5V OUT	14	+5V	Logic power supply
GND	16	GND	Logic ground

7.1.2 Yaskawa Sigma 5 and Sigma 7 CN1 I/O Connector

Name	Pin #	Galil Function	Description
P-OT	CN1-7	Forward Limit Input	Indicates when the forward travel limit sensor has been activated
N-OT	CN1-8	Reverse Limit Input	Indicates when the forward travel limit sensor has been activated
/Home {/S16}	CN1-12	Home Sensor Input	Indicates when the Home Sensor has been activated
/Probe2 {/SI5}	CN1-11	External Latch input	Hardware latch trigger
+24VIN	CN1-6	N/A	Digital input optoisolation common

7.1.3 LS Mecapion Pegasus CN1 I/O Connector

•

Name	Pin #	Galil Function	Description
DI1	2	Forward Limit Input	Indicates when the forward travel limit sensor has been activated
DI2	3	Reverse Limit Input	Indicates when the forward travel limit sensor has been activated
DI3	4	Home Sensor Input	Indicates when the Home Sensor has been activated
PROBE2	5	External Latch input	Hardware latch trigger
+24 VDC	1	N/A	Digital input optoisolation common

7.1.4 LS Mecapion L7NHA CN1 I/O Connector

Name	Pin #	Galil Function	Description
DI1	11	Forward Limit Input	Indicates when the forward travel limit sensor has been activated
DI2	12	Reverse Limit Input	Indicates when the forward travel limit sensor has been activated
DI3	7	Home Sensor Input	Indicates when the Home Sensor has been activated
DI4	8	External Latch input	Hardware latch trigger
+24 VDC	6	N/A	Digital input optoisolation common

7.1.5 Panasonic X4 I/O Connector

•

Name	Pin #	Galil Function	Description
SI-MON2	7	Forward Limit Input	Indicates when the forward travel limit sensor has been activated
SI-MON3	8	Reverse Limit Input	Indicates when the forward travel limit sensor has been activated
SI5	10	Home Sensor Input	Indicates when the Home Sensor has been activated
SI6	11	External Latch input	Hardware latch trigger
I-COM (+24 VDC)	6	N/A	Digital input optoisolation common

7.1.6 Copley Xenus Plus J8 I/O Connector

Name	Pin #	Galil Function	Description
IN3	6	Forward Limit Input	Indicates when the forward travel limit sensor has been activated
IN4	7	Reverse Limit Input	Indicates when the forward travel limit sensor has been activated
IN5	8	Home Sensor Input	Indicates when the Home Sensor has been activated
IN2	5	External latch Input	Hardware latch trigger

7.1.7 Sanyo-Denki R Advanced CN3 I/O Connector

Name	Pin #	Galil Function	Description
CONT1	5,6	Forward Limit	Indicates when forward limit switch has been activated
CONT2	7,8	Reverse Limit	Indicates when reverse limit switch has been activated

7.1.8 Delta ASD-A2 CN1 I/O Connector

Name	Pin #	Galil Function	Description
DI 6	12	Forward Limit Input	Indicates when the forward travel limit sensor has been activated
DI 5	11	Reverse Limit Input	Indicates when the forward travel limit sensor has been activated
DI 4	10	Home Sensor Input	Indicates when the Home Sensor has been activated
СОМ	14	N/A	Digital Input GND

7.1.9 Parker PD-10C - I/O Connector

Name	Pin #	Galil Function	Description
DI 1	11	Forward Limit Input	Indicates when the forward travel limit sensor has been activated
DI 2	12	Reverse Limit Input	Indicates when the forward travel limit sensor has been activated
DI 3	7	Home Sensor Input	Indicates when the Home Sensor has been activated
DI 4	8	External Latch Input	Hardware Latch Trigger
+24 VDC	6	N/A	Digital Input Optoisolation Common

7.1.10 Estun Pronet CN1 IO Connector

Name	Pin #	Galil Function	Description
P-OT	17	Forward Limit Input	Indicates when the forward travel limit sensor has been activated
N-OT	18	Reverse Limit Input	Indicates when the forward travel limit sensor has been activated
HmRef	16	Home Sensor Input	Indicates when the Home Sensor has been activated
DICOM (+24V)	20	N/A	Digital Input Optoisolation Common

7.2 Error Handling

•

Galil EtherCAT Masters include support for drive specific status and error codes. Below are tables containing return values to the EZ command for all supported drives. The _EU1 operand contains a bitmask that corresponds to the error status of each drive on the network.

There are two types of recoverable drive errors. Some errors require that the EtherCAT network be reinitialized (EU0 then EU1) and others require a motor off command (M0). An example of this is a hall error on the AMC-DZE drive which can be simulated by unplugging the encoder while the drive is servoed. #ECATERR will run when a drive reports a fault. Encoder faults are recoverable on the AMC-DZE drive and in this case it can be brought back to the servoed state by clearing the error (reconnecting the encoder), issuing EKm, M0m and then SHm where m is the axis of interest. Consult the drive manufacturer's documentation for recoverable faults.

Please note that some drives take longer to initialize. If a '181- EtherCAT Timeout error' occurs after issuing EU 1, increase the timeout value using the '<' operand. For example, issuing EU1<5500 will allow the EtherCAT network 5500 ms to initialize before timing out. See the DMC-500x0 and DMC-52xx0 Command References for details.

7.2.1 _EU1 Operand

The _EU1 operand stores a bit mask containing the current EtherCAT error state, as shown in Table 20. Note that _EU1 is 0 when no EtherCAT error is detected by the controller for any given axis. There are three types of faults that cause a change in _EU1: A drive fault, an EtherCAT slave not responding or a dropped EtherCAT packet. The _EU1 operand will indicate when a drive on a given EtherCAT axis is faulted. For example, if MG _EU1 prints out the decimal value 36 to the terminal or host, the equivalent binary value is 0000 0000 0010 0100, indicating that a fault has occurred on both the C and F axes. An error code is a numerical value that contains information about the type of fault that occurred on a drive. Error codes are drive specific but may include under voltage, over current and over temperature among other conditions. These more specific values can be queried with the EZ command.

_EU1 Bit	Cause
0	Fault on axis A
1	Fault on axis B
2	Fault on axis C
3	Fault on axis D
4	Fault on axis E
5	Fault on axis F
6	Fault on axis G
7	Fault on axis H
8-14	Reserved
15	EtherCAT network error

Table 20: _EU1 operand status bits

7.2.2 EK - Clear EtherCAT Error

When an EtherCAT error occurs, The _EU1 operand is populated with the drive fault status bit

mask for all axes. After resolving the issue that caused the fault(s), EK _EU1 can be issued to clear all drive's error status bits. Note that some drives require that the EtherCAT Network be reinitialized or a that the drive be power cycled in order to clear error conditions. Consult the drive documentation for specifics.

7.2.3 EZ - EtherCAT Errors

•

Drive specific error codes can be interrogated using the EZ command and _EZmn operand, where m is the axis of interest. When the EZ command is issued, the _EZmn operands are assigned the error code value and can be interrogated from the terminal or host PC.

When EZ 1 is issued, the controller will return a list of the drives that have reported errors along with their corresponding error codes in the format shown in Table 21. Each field of the _EZm operand contains a 2 byte number that reflects the error reported. Not all fields are used by all vendors. Consult the drive's user manual for more information on error codes, their location and their meaning.

Axis [m]	Vendor	EZm0	EZm1	EZm2	EZm3	EZm4	EZm5	EZm6	EZm7	Error
A	Delta	\$7305	\$0000	\$0000	\$0000	\$0000	\$0000	\$0000	\$0000	Encoder Data Error
С	Mecapio n	\$0028	\$0000	\$0000	\$0000	\$0000	\$0000	\$0000	\$0000	Under Voltage

Table 21: EZ return values for Delta and LS Mecapion Drives

7.2.4 #ECATERR - EtherCAT Error Automatic Subroutine

#ECATERR is an automatic subroutine that interrupts thread zero and executes when there is an EtherCAT error. EtherCAT Errors are defined as either alarms raised on individual drives or network wide. For instance a severed CAT5 cable would raise trigger the #ECATERR routine.

This allows the user to create an automated custom response under fault conditions. The #ECATERR subroutine can be used to alert a user or system to EtherCAT drive faults and take appropriate actions. See section Example 3: EtherCAT Error Handling in Chapter 6 for sample DMC code illustrating uses of the #ECATERR subroutine.

7.2.5 Drive Specific Error Codes

This section lists some of the drive error codes for each drive compatible with Galil EtherCAT Masters. Consult the drive's documentation for a full list of error codes and descriptions.

1 AMC

AMC-DZE drive responses to the EZ command are bit masks that must be interpreted according to the drive documentation. For example if the _EZA2 operand contains the number 4, the equivalent binary value is 0000 0000 0000 0100 indicating that there is an invalid hall state on the A axis. See Table 22 for a short list of AMC drive error codes.

Operand	Bit	Error Description
_EZm1	4	Under Voltage
_EZm1	3	Over Current
_EZm3	14	Shunt Regulator
_EZm2	6	Feedback Sensor Error

Table 22: Example AMC DZE Drive Error Codes

2 Yaskawa

•

Some example Yaskawa $\Sigma V/\Sigma VII$ drive responses to the EZ command are shown in Table 23. The "A" in the error code is not included in the returned value, only the hexadecimal number following it. These codes are also shown on the Yaskawa ΣV drive's 7 segment LED display.

Value	Error Description
0x410	Under Voltage
0x840	Encoder Data Error
0xCA0	Encoder Parameter Error
0x300	Regeneration Error

Table 23: Example Yaskawa ΣV Drive Error Codes

3 Panasonic

The Panasonic MINAS-A5BA4 reports only the main alarm number as a hexadecimal. The lower 8 bits of the value (FF00h to FFFFh) indicate the main alarm number as listed in Table 24

Value	Error Description
12.0	Over voltage protection
16.0	Over-load protection
21.1	Encoder communication error
27.7	Position information initialization error

Table 24: Example Panasonic MINAS A5B Error Codes

4 Copley

The Copley Xenus Plus Model XEL-230-36 reports errors to a 32-bit object that is a bit-mapped status register with the fields defined in Table 25.

Bit	Error Description
0	Short Circuit Detected
4	Motor Temp. Sensor Active
21	Position has wrapped
29	Motor phase not yet initialized

Table 25: Example Copley Xenus Plus Error Codes

5 Sanyo-Denke

•

The Sanyo-Denki RS2A01A0KA4 drive displays errors, referred to as 'Alarms' with hexadecimal values. Some values for these alarms are shown below in Table 26

Value	Error Description
0x52	RS Overheat
0x22	Current Detection Error 0
0x62	Main Circuit Under Voltage
0x81	Encoder 1 Disconnected

Table 26: Example Sanyo-Denke R Advanced Error Codes

6 LS Mecapion

Example Pegasus and L7NHA error codes are listed below in Table 27. These codes are also displayed on the drive's 4 digit LED display as 'Alarms'.

Value	Error Description	
14	Over Current	
23	Regeneration Overload	
30	Encoder Cable Error	
40	Under Voltage	

Table 27: Example LS Mecapion Error Codes

7 Delta

Delta Error Codes are listed in Table 28. These codes are also displayed on the drive's 4 digit LED display.

Value	Error Description	
2310	Over Current	
7122	Motor Error	
7305	Encoder Data Error	
3300	U,V,W wiring error	

Table 28: Example Delta Electronics Drive Error Codes

8 Parker

Parker PD-10C Error Codes are listed in Table 29. These codes are also displayed on the drive's 4 digit LED display.

Value	Error Description	
14	Over Current	
24	Motor Error	
32	Encoder Data Error	
40	Under Voltage	

Table 29: Example Parker Drive Error Codes

9 Estun

•

Estun Pronet Error Codes are listed in Table 30. These codes are also displayed on the drive's 4 digit LED display.

Value	Error Description	
04	Torque Limit Exceeded	
12	Over Current	
14	Under Voltage	
16	Regenerative Error	

Table 30: Example Estun Pronet Drive Series Error Codes

7.3 EtherCAT Glossary

Term	Definition		
Clockwise	Defined as the direction of rotation as seen when facing the "front" of the motor.		
Counter Clockwise	Defined as the direction of rotation as seen when facing the "front" of the motor.		
Cyclic Position Mode	Set with the MT 10 command. Configures the Galil EtherCAT Master to output motion profiling data. Servo loop PID tuning is left to the external drive.		
Cyclic Torque Mode	Set with with the MT 11 command, closes the servo loop on the DMC-500x0 EtherCAT Master.		
Drive Fault	A condition that causes a drive to cease functioning as expected on the EtherCAT network.		
EtherCAT	Communication protocol allowing communication between an EtherCAT Master and external servo drives over CAT5 Ethernet cables.		
EtherCAT "Up"	Configure and initialize an EtherCAT network using the EX and EU commands. Refer to the command reference for details.		
EtherCAT "Down"	Disable a configured and initialized EtherCAT network using the EU command.		
EtherCAT Axis	An axis that has been selected for use with an EtherCAT drive and is initialized with the EX and EU commands. Refer to the command reference for details.		
EtherCAT Drives	Used interchangeably with EtherCAT slaves.		
EtherCAT Master	A motion controller that is configured to communicate with and control a network of EtherCAT enabled drives. An EtherCAT Network can include only one EtherCAT Master.		
EtherCAT Slave	An EtherCAT drive that is on the same EtherCAT network as the Galil EtherCAT Master. This drive may or may not be exchanged for a local axis. Used interchangeably with EtherCAT drives .		
Galil BLM	Galil 3 phase brushless motor part # BLM-N23-50-1000-B. "Free spinning" refers to a motor that is not attached to any external mechanics.		
Initialization	The process of assigning a local axis to an EtherCAT station and initializing the EtherCAT Network with the EX and EU commands. Refer to the command reference for details.		
Local Axis	An axis that has not been assigned or initialized for use with EtherCAT axis. This axis will function as described in the DMC-500x0 and DMC-52xx0 User Manuals.		
Position	Each EtherCAT station has a physical position within the daisy chain. This position can be queried using the EH command. The EX command uses the Station ID to assign and EtherCAT axis. Refer to the command reference for details.		

<u>•</u>	Galil Motion Cont	rol
Station ID	Each EtherCAT station needs a unique address on the EtherCAT network, this address is called the Station ID. Most EtherCAT axes are assigned a Station ID using rotary or other physical switches present on the drive. The EX command uses the Station ID to assign an EtherCAT station to a local axis. Refer to the command reference for details.	
	Table 31: Definition of Terms used in this Setup Guide	
Galil EtherCAT Ma	ster Setup Guide Rev 1.0d	59

7.4 Galil BLM-N23-1000-B Specifications

•

Specification	Units	Value
K_{τ} - Torque Constant	N•m/A	0.08
	oz•in/A	12.1
T _P - Peak Torque	N•m	0.83
	oz∙in	120
T _c - Continuous Torque	N•m	0.39
	oz∙in	55
Continuous Current	A	4.9
Peak Current	A	10.4
J _m - Moment of Inertia	kg•m²	2.5 x 10 -5
	oz•in•s²	3.5 x 10 -3
Maximum speed	rpm	5000
Resistance	Ω	1.2
Inductance	mH	2.6
K _v Motor Constant	V/krpm	29
Encoder Resolution	counts/rev	4000

Table 32: Galil BLM Motor Specifications

